

Sunny Tripower CORE1 Accessories – SPD Kits



- The CORE1 can accept protection modules (Type 2 or 1+2) for the PV inputs and the AC output.

Type 1 = lightning protection; can be located on line side of service OCPD

Type 2 = surge protection; located on load side of service OCPD

PV inputs

(DC_SPD_KIT4-10) – Type 2

(DC_SPD_KIT5_T1T2) – Type 1+2

- 9 modules (6x PV+, 2x PV-, 1 PV-PE)



Accessory kits are ONLY the SPD modules – the holders are factory installed and ready to be populated

AC output

(AC_SPD_KIT1-10) – Type 2

(AC_SPD_KIT2_T1T2) – Type 1+2

- 4 modules (L1/L2/L3/N)

